



1. Open the  **GPS Update Tool.exe** tool. And connected with the GPS to PC, you will find the below update interface:
TODO: <文件说明>
TODO: <公司名>



2. Click “Open” to choose the .dwm file you have saved, and click update to begin the gps data update progress.
3. After the upgrade, you can click the “Setting” to set the parameters of screen light and radar bands as below:



4. Confirm by OK to configure the parameters setting. And exit by click the “close” on the right below side.